



WRK (Wood Repair Kit)

Frontier Products, Inc.
4524 J D Mouser Parkway
Alvarado, TX 76009
Ph: 682-422-3817
www.frontierproductsinc.com



PRODUCT DESCRIPTION
WRK is a complete professional wood floor repair system used for repairing hollow spots, loose areas, and end lifting.

Can be used to repair:

- Vinyl Composition Tile (VCT)
- Luxury Vinyl Tile/Plank (LVT)
- Rubber Tile
- Cork Tile
- Cork Underlayment

Packaging
Quantity

Description

Quantity	Description
1	One Quart Frontier WRA
1	60 CC Plastic Syringe
2	Metal Applicator Tips
2	Drill Bits
8	Dowels
1	Dowel Punch

WARRANTY

This product is manufactured according to exacting quality control standards and is warranted to be free from manufacturing defects. Defective material called to our attention within one year of manufacture will be replaced. No guarantee, expressed or implied, is made regarding the performance of this product since the manner and conditions of application are beyond our control.

Refill Adhesive available in Quarts and Gallons.



Made in the U.S.A.

INSTALLATION

- Locate loose area(s) in the wood and outline with releasable tape. Prepare all hollow areas at the same time. Doing all repairs in a short time period will prevent the syringe from clogging.
- Stir adhesive before using.

Loading The Syringe: (two options)

1. Pour directly from bottle into syringe.
2. Pour WRA into an open container. Place the applicator tip of syringe into open container and draw the adhesive up into syringe.

Note: Adhesive is thin – it will drip without pressure being applied to the syringe.

- Drill hole(s) with the drill bit provided in this system in the area outlined by the tape. There may be a need for more than one hole per loose area depending upon size. For larger areas, at least two holes are recommended. Drill one hole at one side of the hollow area and a second hole at the other side.
- Place the applicator tip into the hole and inject adhesive until you feel back pressure. If two holes were drilled, inject adhesive until it comes out the other hole. There may be a need to inject adhesive into the second hole to spread the repair adhesive to the entire area.
- The hollow spot should now be filled in completely. Do not weigh down the repaired area.
- Once the void is completely filled use the dowels provided as a plug for the hole(s) drilled. This will keep the adhesive securely under the floor. The dowel is slightly oversized and needs to be tapered with a knife or sandpaper to properly fill the hole. Tap the dowel into the hole and cut it off even with the floor. Use the dowel punch provided in this system to lower the dowel below the surface of the flooring. Putty the hole with wood filler that blends with the floor color.
- Clean up any adhesive residue with a damp cloth. Dry adhesive can be removed with UA-R. Clean out syringe and applicator tip so that it can be reused.

Note: This repair system can be used with most glue down wood floors, as long as the adhesive is completely cured. Restrict foot traffic for 24 hours.

Caution

If there is a large amount of repair adhesive used to fill a hollow spot, some cupping of the floor may occur. This cupping will dissipate within several days.

KEEP ADHESIVE FROM FREEZING.