



UA-R

1 of 2

Frontier Products, Inc.
4524 J D Mouser Parkway
Alvarado, TX 76009
Ph: 682-422-3817
www.frontierproductsinc.com



PRODUCT DESCRIPTION

FPI UA-R is a superior, highly refined solvent formulation designed for cleaning up uncured urethane adhesives from prefinished wood flooring and other surfaces.

Advantages

- Removes uncured urethane from wood flooring surfaces
- Cleans tools
- No odor
- Formulated for professionals

Packaging

32 OZ (1 QT) packed, 6 per case

Cautions and Limitations

Remove excess adhesive before it cures. UA-R will not remove cured adhesive. Use a clean, soft cloth that will not damage the floor. Do not allow UA-R to run into the joints of the flooring during application. Avoid contact with eyes and prolonged contact with skin.

For professional use only.

Not for sale or use in California.

FOR USE AS A SURFACE CLEANER

1. Apply UA-R to a clean, soft cloth.
2. Gently wipe clean, the affected area, applying more UA-R to the cloth when necessary. Use another clean cloth and repeat if needed.
3. After the adhesive has been removed, wipe off any residue with a dry clean cloth.

FOR USE AS A TOOL CLEANER:

1. Apply UA-R to a clean cloth or soak the tool with UA-R.
2. Wipe or scrape the adhesive from the tool.

TECHNICAL DATA

Physical State: Liquid
Color: Clear
Flash point: 118°F – TAG Closed Cup
VOC: 782 g/L
Specific Gravity: 0.76 @ 15.6°C (60.1°F)
Shelf Life: 12 months in an unopened container

SAFETY DATA

DANGER! HARMFUL OR FATAL IF SWALLOWED.

EYE IRRITANT. COMBUSTIBLE.

Contains Petroleum Distillates.

Keep away from heat, sparks, open flames, and other ignition sources. Wear goggles and gloves. If the work area is not well ventilated, do not use UA-R.

FIRST AID - IF SWALLOWED, do not induce vomiting. Immediately call poison control center or hospital emergency room.

IN CASE OF EYE CONTACT, immediately flush with water for at least 15 minutes, then get medical attention.

IN CASE OF PROLONGED SKIN CONTACT, wash thoroughly with soap and water. If irritation persists, get medical attention.

KEEP OUT OF REACH OF CHILDREN.

STORAGE

Do not use or store UA-R near sources of heat or open flame, furnaces, pilot lights, stoves, etc. Store UA-R in a cool dry place, out of direct sunlight, at temperatures below 90°F as high temperatures or prolonged exposure to sun may cause container to swell or leak. Keep container closed when not in use.

LIMITED WARRANTY

UA-R is warranted to be free of manufacturing defects for a period of one year from the date of manufacture. Any product found to be defective by Frontier Products will be replaced or the purchase price refunded. Suitability of UA-R for an intended use shall be entirely up to the user. Frontier Products assumes no responsibility for personal injury or property damage since the conditions under which UA-R is transported, stored, sold, used or applied is beyond our control. No other warranties are expressed or implied.